






Concise Beam

Precast/Prestressed Beam Design

A state-of-the-art, easy-to-use Windows based program for the analysis and design check of precast concrete beams, prestressed or not, to American, Canadian, Australian, and New Zealand design standards.



Main Window






Beam Layouts

- Simply supported precast beams
- Cantilever at either end
- Composite topping/slab with optional haunch
- Shored construction optional
- Hollow-core fill
- Automatic generation of openings



Beam Definition






Beam Cross-Sections

- Model any user defined cross-section
- Select from a library of standard sections
- Use the section editor to create your own section, or modify a standard section
- Vary the section prismatically over the length of the beam



Section Editor






Reinforcement Options

- Reinforced, partial or fully-prestressed, precast beams
- Mix of rebar, wire, and strand
- Deflected and debonded strands
- Fully developed or hooked rebar and strand ends available
- Epoxy coated reinforcing bar available




Rebar





Prestressing






Section, Material and Loading Libraries

- Libraries of standard beam cross-sections
- Libraries of standard materials
 - reinforcing steel sizes and material
 - prestressing strand sizes and material
- Libraries of Moving Loads
- Create your own libraries



Section Library







Applied Loads


- Automatic beam and topping self-weight
- Static Point loads, moments or torques
- Uniform, or linearly varying, distributed loads or torques
- Moving Loads including Highway Live Loads



Flexible Load Groups










Design Codes

- American standard ACI 318-99 through ACI 318-14
- Canadian standard CSA A23.3-94 through CSA A23.3-14, CSA S6-06S-10 and CSA S6-14
- Australian standard AS 3600-2001 and 2009
- New Zealand standard NZS 3101:2006
- Customize select code parameters



Customized Code Parameters






Units of Measure

- Work in metric or U.S. Customary (Imperial) units
- Switch back and forth at any time
- Select specific unit of measure (m, cm, mm, in, ft, etc.)
- Save your selection for future use



Flexible Units of Measure






Advanced Engineering Capability

- Uses detailed methods whenever appropriate
- Provides select alternative methods
- Cracked section analysis
- Strain compatibility analysis including slippage of reinforcement
- Lateral stability check during lifting and transport
- Shear check of hollow-core with filled cores



Loss and
Design
Parameters





Analysis and Design Features

- Serviceability and Ultimate State Analyses
- Automatic design code checks
- Shear and torsion steel design
- Interface shear design for deck/topping
- Follows recognized methods as used in the PCI Design Handbook, CPCI Metric Design Manual, and the NPCAA Precast Concrete Handbook




Ease of Use

- Standard Microsoft Windows desktop interface
- Easy-to-read on-screen user's manual and context-sensitive help
- Design tutorial and examples
- Full technical support
- Regular program upgrades



On-Line Help






Text Output

- Summary text report of input and output
- Detailed text reports of analysis and design check results for:
 - Flexure, shear, and torsion analysis
 - Prestress loss and force
 - Concrete stresses and cracking estimate
 - Deflection and camber estimates
 - Flexural, shear, and torsion design checks
 - Stirrup, interface tie and hollow-core fill design checks




Summary Text Report





Detailed Text Reports






Graph Output

- Graphs of analysis and design check results for:
 - Flexure, shear, and torsion analysis
 - Prestress forces
 - Concrete stresses
 - Deflection and camber estimates
 - Flexural and shear design checks
 - Stirrup, hollow-core fill and interface tie design checks

BLACK MINT SOFTWARE

Graphs





Computer Requirements

- Simply, any computer capable of running Microsoft Windows XP or later, including Windows 10
- Supports any Windows installed printer or PDF printer
- Internet access and e-mail address for program distribution, updates, announcements, and technical support



How to Obtain Concise Beam

- Visit Black Mint Software's web site at www.BlackMint.com to download a free 30 day, fully-functional, evaluation copy of the program
- Current pricing, ordering, and payment options are available on the web site
- Black Mint Software can also be reached through the web site to answer any of your questions



Visit Us at www.BlackMint.com

Contact Us at ConciseBeam@BlackMint.com

